

ELECTRICAL SAFETY RECALL

Rechargeable Battery Pack for CF-H2 Panasonic Tablet

Battery Pack Model CF-VZSU53AW



Panasonic CF-H2



CF-VZSU53AW

Lot Number

Manufacturing Lot Number (4 digit alpha numeric code). All lots beginning with the letter:
B, C1, C2, C3, C4, C5, C6, C7, C8, C93, C94, C96, C9C, C9J, C9K

IDENTIFICATION: Model CF-VZSU53AW

Manufacturing Lot Numbers beginning with: B, C1, C2, C3, C4, C5, C6, C7, C8, C93, C94, C96, C9C, C9J, C9K - The model number and the lot number can be found on the sticker attached to the battery as shown above. All lots beginning with the letter "B" with any combination of letters or numbers following the letter "B" are included in this recall. This battery is used for the CF-H2 Panasonic Tablet and was sold with the Tablet and separately, as accessories in Australia from June 2011 to June 2014.

DEFECT: The battery may contain manufacturing defects and may overheat.

HAZARD: There is a risk that the battery pack may overheat and cause smoke or may ignite posing the risk of fire or burn hazard to consumers and to the CF-H2 Panasonic Tablet.

ACTION REQUIRED: Immediately turn off the CF-H2 Panasonic Tablet and inspect it to see if it contains the defective battery with the Manufacturing Lot Number. Remove the battery (normally two per Tablet) and only use the Tablet with the AC Adapter and power cord from mains power until the battery is replaced. Contact Panasonic to determine if you are affected and to arrange for a free replacement battery (or two per Tablet).

For further information: Contact Panasonic on the toll free number 1300 665 507 Monday to Friday between 8.30am and 6.00pm (AEST) or via email at: panasonicCFH2battery@panasonic.mailus.com.au or go to www.panasonic.com.au

See www.recalls.gov.au for Australian product recall information