

Product Safety Recall



Product: LED Pumpkin Spinning Wand

Keycode 60508690

Sale period: September 2017 – October 2017



Sold at Target Australia Stores including Target Country during the dates stated above.

Defect: The battery compartment cover may be opened, exposing the button batteries inside.

Hazard: If young children gain access to the button batteries and ingest them, they may suffer internal burn injuries, which can result in serious illness and even death. In addition, the batteries may pose a choking hazard to young children.

What to do: We recommend you stop using the product and return the product to a Target or Target Country store as soon as possible, where our team members will provide you with a full refund.

Contact Details: If you require further information, please contact our Customer Support Centre on 1300 753 567.

**See www.recalls.gov.au for
Australian Product Recall Information**